B
BLÜEMLISALP
Fine Swiss Alpine Lifestyle



Blüemlisalp ist das Label für einen gehobenen Alpinen Lifestyle aus der Schweiz. In der Schweiz entwickelt und in der Schweiz produziert.

Wir nehmen Traditionen der alpinen Schweiz auf, interpretieren diese neu und kreieren unverwechselbare Trachtenmode, charmante Accessoires, liebevollen Schmuck und einzigartige Uhren.

Der Name Blüemlisalp leitet sich von einem stark vergletscherten Bergmassiv im Herzen der Berner Alpen ab, welches bei klarer Sicht selbst von Süddeutschland aus sichtbar ist.

Blüemlisalp, the label developed and manufactured in Switzerland, represents the high-class Alpine lifestyle.

We re-interpret the venerable traditions of Alpine Switzerland to create distinctive contemporary fashion in the traditional style, charming accessories, lovingly designed jewelry and unique watches.

The name Blüemlisalp comes from a massif covered by glaciers in the heart of the Bernese Alps, which is visible from southern Germany in clear weather.

Garantie

Auf Ihre Blüemlisalp Markenuhr gewähren wir ab dem Kaufdatum eine Garantie von zwei Jahren gemäss den geltenden Garantiebedingungen.

Die Garantie gilt für folgende Bauteile: Uhrwerk, Zeiger und Zifferblatt. Sollte eines der vorstehend genannten Teile innerhalb der Garantiezeit bei normalem Gebrauch Materialdefekte oder Verarbeitungsfehler aufweisen, wird die betreffende Uhr nach Ermessen entweder gebührenfrei repariert oder gegen eine andere Uhr ausgetauscht (die entsprechende Entscheidung obliegt ausschließlich bei Blüemlisalp). Als Eigentumsnachweis müssen Sie den entsprechenden Kaufbeleg vorlegen.

Die Herstellergarantie bezieht sich nicht auf:

- Batterie (bei Quarzwerk), Gehäuse, Uhrglas, Verschluss oder Armband
- Schäden, die durch unsachgemäße Behandlung, Fahrlässigkeit, Unfall oder normale Abnutzung entstehen
- Wasserschäden. Die Uhr ist bis 3 ATM wasserdicht, was einen Schutz bei Händewaschen, Regen, u.ä. bedeutet. Schwimmen, Duschen, Tauchen, etc. sind jedoch nicht möglich und führen zu Schäden.
- Die Garantie erlischt, wenn die Uhr durch Unfall, Fahrlässigkeit, unsachgemäße Reparatur oder andere Umstände beschädigt wird, die nicht auf Materialdefekte oder Verarbeitungsfehler zurückzuführen sind.

Bitte senden Sie Ihre Uhr zusammen mit Ihrem Kaufbeleg und der entsprechenden Problembeschreibung an XANTIA SA, Gurzelenstrasse 16, PO Box 4062, CH-2500 Biel/Bienne.

Bei Reparaturarbeiten, die nicht unter die Bestimmungen dieser Garantie fallen, kann Ihnen Blüemlisalp die entsprechenden Kosten in Rechnung stellen.

Bitte senden Sie Ihre Uhr nicht mit der Originalverpackung ein, da diese nicht an Sie zurückgesendet werden kann. Blüemlisalp empfiehlt Ihnen, dass Sie Ihre Uhr als versichertes Päckchen versenden und darauf achten, dass Sie die Uhr für den Transport sicher verpacken. Blüemlisalp übernimmt keine Haftung, falls Ihre Uhr beim Transport beschädigt wird oder verloren geht.

Im Weiteren verweisen wir auf die AGB auf unserer Website www.blueemlisalp.ch

Bedienungsanleitung

Quarzwerk

Quarzuhren verfügen in der Regel über eine Gangreserve von über 3 Jahren im Dauerbetrieb. Die entladene Batterie kann durch einen Uhrenfachhändler ausgetauscht werden.

Einstellen der Zeit:

– Krone ganz herausziehen, die Uhr stoppt
– Durch Drehen der Krone die richtige Zeit einstellen
– Eindrücken der Krone, die Uhr beginnt wieder zu laufen

Wenn Sie Ihre Uhr für einige Wochen oder Monate nicht zu tragen gedenken, ziehen Sie die Krone bis zur letzten Rastposition heraus, bevor Sie die Uhr weglegen. Auf diese Weise wird der Energieverbrauch reduziert.

Automatikwerk

Automatik-Armbanduhren werden von einem Rotor aufgezogen, der sich während des Tragens hin und her bewegt und so die Feder spannt. Eine voll aufgezogene Uhr hat eine Gangreserve von 42 Stunden.

Zum Aufziehen der Uhr die Krone hin und her bewegen, bis die Feder voll aufgezogen ist.

Wenn die Uhr nur gelegentlich getragen wird oder wenig bewegt wird, muss die Feder der Uhr von Hand wieder aufgezogen werden.

Einstellen der Zeit:

– Die Krone nun bis zum Anschlag herausziehen.
– Die Krone so drehen, dass sich beide Zeiger im Uhrzeigersinn bewegen. Danach die Zeiger auf die aktuelle Tageszeit einstellen.
– Die Krone nun voll eindrücken, um die Uhr in Gang zu setzen.

Warranty

The Blüemlisalp watch comes with a two-year warranty valid from the date of purchase in accordance with the applicable terms of the warranty.

The warranty covers the movement, hands and dial. Should one of the aforementioned parts manifest material defects or faulty workmanship under conditions of normal use during the warranty period, the watch concerned will be either repaired free of charge or replaced by another watch (this decision is entirely at the discretion of Blüemlisalp). You must present the receipt of purchase as proof of ownership.

The manufacturer's warranty does not cover the following:

- the battery (if the watch has a quartz movement), the case, the glass, the clasp or the strap;
- damage due to improper handling, negligence, accidents or normal wear;
- water damage. The watch is watertight to 3 ATM, which means that it is protected when you wash your hands, in the rain, etc. However, swimming, showering, diving and similar activities are not to be done while wearing the watch and will result in damage to it.
- The warranty is invalidated when the watch is damaged via accidents, negligence, improper repairs or other circumstances not arising from material defects or faulty workmanship.

Please send your watch together with your proof of purchase and a description of the problem to XANTIA SA, Gurzelenstrasse 16, PO Box 4062, CH-2500 Biel/Bienne.

Blüemlisalp can invoice you for repairs that are not covered by the provisions of this warranty.

Please do not send your watch to us with the original packaging, as the latter cannot be returned to you. Blüemlisalp recommends that you send your watch as an insured package and make sure that you pack the watch safely for shipping. Blüemlisalp is not liable for any damage or loss of the watch that occurs during shipping.

For more information, please refer to our general terms and conditions of business on our website at www.blueemlisalp.ch.

Operating instructions

Quartz movement

As a rule, quartz watches have a power reserve of more than three years in continuous operation. The empty battery can be replaced by a watchmaker.

Setting the time:

– Gently pull the crown out to its full length; the watch will stop.
– Turn the crown to set the correct time.
– Push the crown back in; the watch will start running again.

If you will not be wearing your watch for several weeks or months, gently pull the crown out to the last locking position before putting your watch away. This will reduce the energy consumption.

Automatic movement.

Automatic watches are wound by a rotor that moves back and forth while you are wearing the watch, which tensions the spring. A fully wound watch has a power reserve of 42 hours.

To wind the watch, rotate the crown back and forth until the spring is fully wound.

If the watch is worn only rarely or moved very little, the spring must be wound by hand again.

Setting the time:

– Gently pull out the crown until it stops.
– Rotate the crown so that both hands move clockwise. Then set the hands to the correct time.
– Now push the crown in to the full extent to start the watch.

www.blueemlisalp.ch

Fotos/Pictures: www.oeschinensee.ch